

Dec 01, 23 14:20

## goals9system.py

Page 1/2

```

1  """goals8system.py
2
3      This is the main script that coordinates both the controller and
4      the detector. Feel free to play/edit/...
5
6      """
7
8      # Import the system parts
9      import threading
10     import traceback
11
12     # Import your pieces. Change the "from" names (being the file names)
13     # to the file names of your two code parts. Also, this is a great way
14     # to quickly switch which detector to run. E.g. you could import from
15     # "facedetector" in place or "balldetector".
16     from goals9step6c import controller
17     from goals9step6d import detector
18     # from goals8facedetector import detector      # Alternate option
19
20
21     #
22     # Shared Data
23     #
24     class Shared:
25         def __init__(self):
26             # Thread Lock. Always acquire() this lock before accessing
27             # anything else (either reading or writing) in this object.
28             # And don't forget to release() the lock when done!
29             self.lock = threading.Lock()
30
31             # Flag - stop the detection. If this is set to True, the
32             # detection should break out of the loop and stop.
33             self.stop = False
34
35             # Data - PLEASE UPDATE TO ADD THE DATA YOU NEED!
36             self.newdata = False # Flag to indicate fresh, new data
37             self.deltapan = 0.0 # Relative pan angle
38             self.deltatilt = 0.0 # Relative tilt angle
39             self.scalepan = 0.0
40             self.sharetilt = 0.0
41             self.balls = []
42
43     #
44     # Main Code
45     #
46     def main():
47         # Prepare the shared data object.
48         shared = Shared()
49
50         # Create a second thread.
51         thread = threading.Thread(target=detector, args=(shared,))
52
53         # Start the second thread with the detector.
54         print("Starting second thread")
55         thread.start()      # Equivalent to detector(shared) in new thread
56
57         # Use the primary thread for the controller, handling exceptions
58         # to gracefully shut down.
59         try:
60             controller(shared)
61         except BaseException as ex:
62             # Report the exception
63             print("Ending due to exception: %s" % repr(ex))
64             traceback.print_exc()
65
66         # Stop/rejoin the second thread.
67         print("Stopping second thread...")
68         if shared.lock.acquire():
69             shared.stop = True

```

Dec 01, 23 14:20

## goals9system.py

Page 2/2

```
71     thread.join()          # Wait for thread to end and re-combine.  
72  
73 if __name__ == "__main__":  
74     main()
```

Dec 01, 23 14:09

## goals9step6c.py

Page 1/5

```

1  """goals8step8c.py
2
3  Goals 8 Step 8
4
5  """
6
7  # ----- SETUP THE KEYBOARD INTERFACE -----
8  # Import the necessary packages
9  import atexit, select, sys, termios
10
11 # Set up a handler, so the terminal returns to normal on exit.
12 stdattr = termios.tcgetattr(sys.stdin.fileno())
13 def reset_attr():
14     termios.tcsetattr(sys.stdin.fileno(), termios.TCSAFLUSH, stdattr)
15 atexit.register(reset_attr)
16
17 # Switch terminal to canonical mode: do not wait for <return> press.
18 newattr = termios.tcgetattr(sys.stdin.fileno())
19 newattr[3] = newattr[3] & ~termios.ICANON
20 termios.tcsetattr(sys.stdin.fileno(), termios.TCSAFLUSH, newattr)
21
22 # Define the kbhit() and getch() functions.
23 def kbhit():
24     return sys.stdin in select.select([sys.stdin], [], [], 0)[0]
25 def getch():
26     return sys.stdin.read(1)
27 #
28
29 # Import useful packages
30 import hebi
31 import numpy as np          # For future use
32 import matplotlib.pyplot as plt
33
34 from math import pi, sin, cos, asin, acos, atan2, sqrt
35 from time import sleep, time
36 import enum
37 def controller(shared):
38     class Mode(enum.Enum):
39         Hold=0
40         Spline=1
41         Scanning =2
42         Reset = 3
43         Setscan = 4
44
45     class Object:
46         def __init__(self, pan = 0.5, tilt = 0.5):
47             self.pan = pan
48             self.tilt = tilt
49             self.conf = 0.2
50
51     mode=Mode.Hold
52
53     #
54     # HEBI Initialization
55     #
56     # Create the motor group, and pre-allocate the command and feedback
57     # data structures. Remember to set the names list to match your
58     # motor.
59     #
60     names = ['9.8', '2.1']
61     group = hebi.Lookup().get_group_from_names(['robotlab'], names)
62     if group is None:
63         print("Unable to find both motors " + str(names))
64         raise Exception("Unable to connect to motors")
65
66     command = hebi.GroupCommand(group.size)
67     feedback = hebi.GroupFeedback(group.size)
68
69     #setup time
70     t0 = 0.0
71     Tmove = 0.0                      # 5 seconds
72     tf = t0 + Tmove
73     T=15
74
75     #
76     # Calibration
77     #
78     calib = np.array([[0], [-pi/6]])
79
80     #Find initial position and velocities
81     feedback = group.get_next_feedback(reuse_fbk=feedback)
82     pinit = np.array([feedback.position[0], feedback.position[1]])
83     p0 = np.array([[pinit[0]],[pinit[1]]])
84     pf = p0
85     phold = p0
86     v0 = np.array([[0.0], [0.0]])
87     vf = np.array([[0.0], [0.0]])
88
89     #
90     # Pre-allocate the storage

```

Dec 01, 23 14:09

## goals9step6c.py

Page 2/5

```

92     N = int(100 * T)           # 100 samples/second.
93     Time = np.array([0.0] * N)
94     PAct = np.array([[0.0] * N] * 2)
95     PCmd = np.array([[0.0] * N] * 2)
96     VAct = np.array([[0.0] * N] * 2)
97     VCmd = np.array([[0.0] * N] * 2)
98     objectpan = np.array([0.5] * N)
99     objecttilt = np.array([0.5] * N)
100    obj = []
101    monitor = []
102    (pan, otilt) = (0.5, 0.5)
103
104    # Initialize the index and time.
105    index = 0
106    t      = 0.0
107
108    #
109    # Maximum Velocities/Accelerations
110    #
111    t_min = np.array([[2], [5]])
112    v_max = 2/3*pi*pi/t_min
113    a_max = v_max/0.25
114
115    #
116    # calculate spline parameters
117    #
118    def splineparameters(Tmove, p0, v0, pf, vf):
119        a = p0
120        b = v0
121        c = 3*(pf-p0)/(Tmove**2)-vf/Tmove-2*v0/Tmove
122        d = -2*(pf-p0)/(Tmove**3)+vf/(Tmove**2)+v0/(Tmove**2)
123        return (a, b, c, d)
124
125    def splinetime(p0, pf, v0, vf):
126        return max(np.amax(1.5*(np.absolute(p0-pf)/v_max+np.absolute(v0)/a_max+np.absolute(vf)/a_max)), 1)
127    #
128    # Plot.
129    #
130    # Create a plot of position and velocity, actual and command!
131    def plotPos():
132        pan = [m.pan for m in monitor]
133        tilt = [m.tilt for m in monitor]
134        plt.scatter(pan, tilt, marker = "X")
135        plt.xlim(-1.5,1.5)
136        plt.ylim(-1.0, 1.0)
137        plt.title('Goals 9 Step 6 – Monitor Multiple Detection')
138        plt.ylabel('Tilt')
139        plt.xlabel('Pan')
140        for m in monitor:
141            print("tilt ", m.tilt, "pan ", m.pan, "confidence ", m.conf)
142        plt.show()
143
144    def plot():
145        fig, (ax1, ax2) = plt.subplots(2, 1, sharex=True)
146        ax1.plot(Time[0:index], PAct[0][0:index], color='blue', linestyle='-', label='Pan PAct')
147        ax1.plot(Time[0:index], PCmd[0][0:index], color='blue', linestyle='--', label='Pan PCmd')
148        ax1.plot(Time[0:index], objectpan[0:index], color='red', linestyle='-', label='Pan object')
149        ax1.plot(Time[0:index], PAct[1][0:index], color='green', linestyle='-', label='Tilt PAct')
150        ax1.plot(Time[0:index], PCmd[1][0:index], color='green', linestyle='--', label='Tilt PCmd')
151        ax1.plot(Time[0:index], objecttilt[0:index], color='black', linestyle='.', label='Tilt object')
152
153        ax2.plot(Time[0:index], VAct[0][0:index], color='blue', linestyle='-', label='Pan VAct')
154        ax2.plot(Time[0:index], VCmd[0][0:index], color='blue', linestyle='--', label='Pan VCMD')
155        ax2.plot(Time[0:index], VAct[1][0:index], color='green', linestyle='-', label='Tilt VAct')
156        ax2.plot(Time[0:index], VCMD[1][0:index], color='green', linestyle='--', label='Tilt VCMD')
157
158        ax1.set_title('Goals 9 Step 3 – Cammera Scale and Latency')
159        ax1.set_ylabel('Position (rad)')
160        ax2.set_ylabel('Velocity (rad/s)')
161        ax2.set_xlabel('Time (s)')
162
163        ax1.grid()
164        ax2.grid()
165        ax1.legend(loc = 'lower right')
166        ax2.legend(loc = 'lower right')
167        #plt.scatter(objectpan, objecttilt)
168        plt.show()
169    ##
170    ## Execute Movement
171    ##
172    while True:
173        # Read the actual data. This blocks (internally waits) 10ms for the data.
174        feedback = group.get_next_feedback(reuse_fbk=feedback)
175        pact = np.array([[feedback.position[0]], [feedback.position[1]]])
176        vact = np.array([[feedback.velocity[0]], [feedback.velocity[1]]])
177        # Compute the commands for this time step
178        if mode is Mode.Scanning:
179            A = np.array([[1.0], [0.5]])
180            Tperiod = np.array([[4], [8]])

```

Dec 01, 23 14:09

# goals9step6c.py

Page 3/5

Dec 01, 23 14:09

## goals9step6c.py

Page 4/5

```

274         vf = np.array([[0.0], [0.0]])
275         Tmove = splinetime(p0, pf, v0, vf)
276         (a, b, c, d) = splineparameters(Tmove, p0, v0, pf, vf)
277         print('B: pan: -45, tilt: -30')
278     elif (ch == 'c'):
279         p0 = pcmd
280         v0 = vcmd
281         pf = np.array([[0],[pi/8]]) + calib
282         vf = np.array([[0.0], [0.0]])
283         Tmove = splinetime(p0, pf, v0, vf)
284         (a, b, c, d) = splineparameters(Tmove, p0, v0, pf, vf)
285         print('C: pan: 60, tilt: 45')
286     elif (ch == 'd'):
287         p0 = pcmd
288         v0 = vcmd
289         pf = np.array([[0],[pi/6]]) + calib
290         vf = np.array([[0.0], [0.0]])
291         Tmove = splinetime(p0, pf, v0, vf)
292         (a, b, c, d) = splineparameters(Tmove, p0, v0, pf, vf)
293         print('D: pan: 0, tilt: -30')
294     elif (ch == 's'):
295         p0 = pcmd
296         v0 = vcmd
297         pf = np.array([[0],[0]])
298         vf = np.array([[0.0], [0.0]])
299         Tmove = splinetime(p0, pf, v0, vf)
300         (a, b, c, d) = splineparameters(Tmove, p0, v0, pf, vf)
301         mode = Mode.Setscan
302         obj = []
303     elif (ch == 'q'):
304         # If we want to quit, break out of the loop.
305         print('Quitting')
306         break
307     else:
308         # Report the bad press.
309         print("Unknown character '%c'" % ch)
310         t0 = np.array(t)
311         tf = np.array(t0 + Tmove)
312 if shared.lock.acquire(timeout=0.001):
313     if shared.newdata:
314         # Compute the object angles.
315         #print("p", shared.deltapan, "t", shared.deltatilt)
316         # Lpan = 0.41709845
317         Lpan = 0.24
318         Ltilt = 0.1
319         R = 0.0
320         minpan = pact[0][0] - vact[0][0] * Lpan - shared.scalepan * 320
321         maxpan = pact[0][0] - vact[0][0] * Lpan + shared.scalepan * 320
322         mintilt = pact[1][0] + vact[1][0] * Ltilt - shared.scaletilt * 240
323         maxtilt = pact[1][0] + vact[1][0] * Ltilt + shared.scaletilt * 240
324         #Ltilt = 0.8100304
325         #Lpan = 0.
326         #Ltilt = 0.1
327         #opan = pact[0][0] - shared.deltapan
328         print("shared", shared.balls)
329         print("monitored", monitor)
330         obj = []
331         for ball in shared.balls:
332             # print(ball.deltapan, ball.deltatilt)
333             opan = pact[0][0] - vact[0][0] * Lpan - ball.deltapan
334             otilt = pact[1][0] + vact[1][0] * Ltilt + ball.deltatilt
335             obj.append(Object(opan, otilt))
336     def closest(mp, mt):
337         minR = 100
338         minO = Object(0, 0)
339         flag = False
340         for o in reversed(obj):
341             if(sqrt((o.pan-mp)**2+(o.tilt-mt)**2)<minR):
342                 flag = True
343                 minR = sqrt((o.pan-mp)**2+(o.tilt-mt)**2)
344                 minO = o
345         if flag:
346             obj.remove(minO)
347         return minO, minR, flag
348     for m in reversed(monitor):
349         cObj, cDist, exist = closest(m.pan, m.tilt)
350         if exist:
351             if cDist < R:
352                 m = cObj
353                 m.conf = min(m.conf+0.2, 1)
354             elif m.pan < minpan or m.pan > maxpan or m.tilt < mintilt or m.tilt > maxtilt:
355                 m.conf = m.conf-0.005
356             if m.conf < -1.0:
357                 monitor.remove(m)
358             else:
359                 m.conf = m.conf-0.1
360             print(len(obj))
361             for o in reversed(obj):
362                 monitor.append(o)
363             """Lpan = 2.5//1.2

```

Dec 01, 23 14:09

## goals9step6c.py

Page 5/5

```
365     opan = pact[0][0] - shared.deltapan
366     otilt = pact[1][0] + shared.deltatilt
367     opan = pact[0][0] + vact[0][0] * Lpan - shared.deltapan
368     otilt = pact[1][0] + vact[1][0] * Ltlt + shared.deltatilt"""
369     """mode = Mode.Spline
370     p0 = pact
371     pf = np.array([[opan], [otilt]])
372     v0 = vact
373     vf = np.array([[0], [0]])
374     Tmove = splinetime(p0, pf, v0, vf)
375     (a, b, c, d) = splineparameters(Tmove, p0, v0, pf, vf)
376     t0 = t
377     tf = t0 + Tmove
378     print("a=", a, "b=", b, "c =", c, "d=", d)
379     print('going to object")"
380     if(index<N):
381         objectpan[index] = opan
382         objecttilt[index] = otilt
383         # Clear the data.
384         shared.newdata = False
385         shared.lock.release()
386     # Check whether we have a new object location.
387     # Advance the index/time.
388     index += 1
389     t      += 0.01
```

Nov 29, 23 21:40

## goals9step6d.py

Page 1/3

```

1  """goals8step8d.py
2
3     Run the face (and eye) detectors and show the results.
4
5
6     # Import OpenCV
7     import numpy as np
8     import cv2
9
10    def detector(shared):
11        class Ball:
12            def __init__(self, pan = 0.5, tilt = 0.5):
13                self.deltapan = pan
14                self.deltatilt = tilt
15                self.conf = 0.2
16
17            # Set up video capture device (camera). Note 0 is the camera number.
18            # If things don't work, you may need to use 1 or 2?
19            #camera = cv2.VideoCapture(0, cv2.CAP_V4L2)
20            camera = cv2.VideoCapture(0, cv2.CAP_ANY)
21
22            if not camera.isOpened():
23                raise Exception("Could not open video device: Maybe change the cam number?")
24
25            # Change the frame size and rate. Note only combinations of
26            # widthxheight and rate are allowed. In particular, 1920x1080 only
27            # reads at 5 FPS. To get 30FPS we downsize to 640x480.
28            camera.set(cv2.CAP_PROP_FRAME_WIDTH, 640)
29            camera.set(cv2.CAP_PROP_FRAME_HEIGHT, 480)
30            camera.set(cv2.CAP_PROP_FPS, 30)
31
32            # Get the face/eye detector models from XML files. Instantiate detectors.
33            faceXML = "haarcascade_frontalface_default.xml"
34            eyeXML1 = "haarcascade_eye.xml"
35            eyeXML2 = "haarcascade_eye_tree_eyeglasses.xml"
36
37            faceDetector = cv2.CascadeClassifier(faceXML)
38            eyeDetector = cv2.CascadeClassifier(eyeXML1)
39
40            # Pick some colors. Note OpenCV uses BGR color codes by default.
41            blue = (255, 0, 0)
42            green = (0, 255, 0)
43            red = (0, 0, 255)
44            white = (255, 255, 255)
45
46            hsv = np.array([])
47            bgr = np.array([])
48
49            #
50            # scale
51            #
52            scalepan = 0.00161932589506
53            scaletilt = 0.00133859370275
54            # Keep scanning, until 'q' hit IN IMAGE WINDOW.
55            while True:
56                # Grab an image from the camera. Often called a frame (part of sequence).
57                ret, frame = camera.read()
58
59                #convert image to hsv
60                hsv = cv2.cvtColor(frame, cv2.COLOR_RGB2HSV)
61
62                # Convert the image to gray scale.
63                gray = cv2.cvtColor(frame, cv2.COLOR_BGR2GRAY)
64
65                # Grab the faces - the cascade detector returns a list faces.
66                faces = faceDetector.detectMultiScale(gray,
67                    scaleFactor = 1.2,
68                    minNeighbors = 5,
69                    minSize = (30,30),
70                    flags = cv2.CASCADE_SCALE_IMAGE)
71
72                # Process the faces: Each face is a bounding box of (x,y,w,h)
73                # coordinates. Draw the bounding box ON THE ORIGINAL IMAGE.
74                if len(faces) > 0:
75                    # Grab the first face.
76                    face = faces[0]
77
78                    # Grab the face coodinates.
79                    (x, y, w, h) = face
80
81                    # Draw the bounding box on the original color frame.
82                    #cv2.rectangle(frame, (x, y), (x+w-1, y+h-1), green, 3)

```

Nov 29, 23 21:40

## goals9step6d.py

Page 2/3

```

84      # Also look for eyes - only within the region of the face!
85      # This similarly a list of eyes relative to this region.
86      eyes = eyeDetector.detectMultiScale(gray[y:y+h,x:x+w])
87
88      # Process the eyes: As before, eyes is a list of bounding
89      # boxes (x,y,w,h) relative to the processed region.
90      for (xe,ye,we,he) in eyes:
91          # Can you draw circles around the eyes? Consider the function:
92          # cv2.circle(frame, (xc, yc), radius, (b,g,r), linewidth)
93          pass # replace this.
94
95
96      # Show the image with the given title. Note this won't actually
97      # appear (draw on screen) until the waitKey(1) below.
98      (H, W, D) = frame.shape
99      #np.append(bgr, frame[W//2, H//2])
100     #np.append(hsv, hsv[W//2, H//2])
101     #print("Frame: ", frame[W//2, H//2])
102     #print("HSV: ", hsv[W//2, H//2])
103
104     #Convert to binary
105     binary = cv2.inRange(hsv, (113, 126, 78), (151, 255, 225))
106     #binary = cv2.inRange(hsv, (107, 142, 119), (119, 255, 255))
107
108     #Erode, then Dilate
109     binary=cv2.erode( binary, None, iterations=3)
110     binary=cv2.dilate(binary, None, iterations=3)
111
112     #Dilate, then Erode
113     binary=cv2.dilate(binary, None, iterations=3)
114     binary=cv2.erode(binary, None, iterations=3)
115
116     #Contours
117     (contours, hierarchy) = cv2.findContours(binary, cv2.RETR_LIST, cv2.CHAIN_APPROX_SIMPLE)
118     contoursTemp = sorted(contours, key=cv2.contourArea, reverse=True)
119     contours=[]
120     (xmax,ymax,rmax) = (0, 0, 0)
121     balls = []
122     for contour in contoursTemp:
123         if cv2.contourArea(contour) > 2000:
124             contours.append(contour)
125             ((xr, yr), radius) = cv2.minEnclosingCircle(contour)
126             cv2.circle(frame, (int(xr), int(yr)), 4, (91, 252, 104), -1)
127             cv2.circle(frame, (int(xr), int(yr)), int(radius), (91, 252, 104), 3)
128             x = scalepan * float(xr - 320)
129             y = scaletilt * float(yr - 240)
130             balls.append(Ball(x, y))
131             #print(xr, yr)
132         if shared.lock.acquire():
133             """if rmax > 0:
134             (x0, y0, x, y) = (320, 240, xmax, ymax)
135             shared.deltapan = scalepan * float(x - x0)
136             shared.deltilt = scaletilt * float(y - y0)
137             shared.newdata = True"""
138             shared.balls = balls
139             shared.lock.release()
140             shared.scalepan = scalepan
141             shared.scaletilt = scaletilt
142             shared.newdata = True
143
144     """ENCLOSING CIRCLE"""
145
146
147     cv2.line(frame, (W//2,0), (W//2,H), (0,0,255), 1)
148     cv2.line(frame, (0,H//2), (W, H//2), (0,0,255), 1)
149     cv2.line(hsv, (W//2,0), (W//2,H), (0,0,255), 1)
150     cv2.line(hsv, (0,H//2), (W, H//2), (0,0,255), 1)
151     cv2.imshow('Processed Image', frame)
152     #cv2.imshow('HSV Funkiness', hsv)
153     cv2. imshow('Binary Image', binary)
154
155     # Check for a key press IN THE IMAGE WINDOW: waitKey(0) blocks
156     # indefinitely, waitkey(1) blocks for at most 1ms. If 'q' break.
157     # This also flushes the windows and causes it to actually appear.
158     if (cv2.waitKey(1) & 0xFF) == ord('q'):
159         break
160
161     # Check if the main thread signals this loop to end.
162     if shared.lock.acquire():
163         stop = shared.stop
164         shared.lock.release()
165         if stop:
166             break

```

Nov 29, 23 21:40

## goals9step6d.py

Page 3/3

```
167     camera.release()
168     cv2.destroyAllWindows()
169
170 if __name__ == "__main__":
171     controller()
```

Nov 30, 23 16:20

## goals9step7c.py

Page 1/5

```

1  """goals8step8c.py
2
3  Goals 8 Step 8
4
5  """
6
7  # ----- SETUP THE KEYBOARD INTERFACE -----
8  # Import the necessary packages
9  import atexit, select, sys, termios
10
11 # Set up a handler, so the terminal returns to normal on exit.
12 stdattr = termios.tcgetattr(sys.stdin.fileno())
13 def reset_attr():
14     termios.tcsetattr(sys.stdin.fileno(), termios.TCSAFLUSH, stdattr)
15 atexit.register(reset_attr)
16
17 # Switch terminal to canonical mode: do not wait for <return> press.
18 newattr = termios.tcgetattr(sys.stdin.fileno())
19 newattr[3] = newattr[3] & ~termios.ICANON
20 termios.tcsetattr(sys.stdin.fileno(), termios.TCSAFLUSH, newattr)
21
22 # Define the kbhit() and getch() functions.
23 def kbhit():
24     return sys.stdin in select.select([sys.stdin], [], [], 0)[0]
25 def getch():
26     return sys.stdin.read(1)
27 #
28
29 # Import useful packages
30 import hebi
31 import numpy as np          # For future use
32 import matplotlib.pyplot as plt
33
34 from math import pi, sin, cos, asin, acos, atan2, sqrt
35 from time import sleep, time
36 import enum
37 def controller(shared):
38     class Mode(enum.Enum):
39         Hold=0
40         Spline=1
41         Scanning =2
42         Reset = 3
43         Setscan = 4
44
45     class Object:
46         def __init__(self, pan = 0.5, tilt = 0.5):
47             self.pan = pan
48             self.tilt = tilt
49             self.conf = 0.2
50
51     mode = Mode.Scanning
52
53     #
54     # HEBI Initialization
55     #
56     # Create the motor group, and pre-allocate the command and feedback
57     # data structures. Remember to set the names list to match your
58     # motor.
59     #
60     names = ['9.8', '2.1']
61     group = hebi.Lookup().get_group_from_names(['robotlab'], names)
62     if group is None:
63         print("Unable to find both motors " + str(names))
64         raise Exception("Unable to connect to motors")
65
66     command = hebi.GroupCommand(group.size)
67     feedback = hebi.GroupFeedback(group.size)
68
69     #setup time
70     t0 = 0.0
71     Tmove = 8                      # 5 seconds
72     tf = t0 + Tmove
73     T=15
74
75     #
76     # Calibration
77     #
78     calib = np.array([[0], [-pi/6]])
79
80     #Find initial position and velocities
81     feedback = group.get_next_feedback(reuse_fbk=feedback)
82     pinit = np.array([feedback.position[0], feedback.position[1]])
83     p0 = np.array([[pinit[0]],[pinit[1]]])
84     pf = p0
85     phold = p0
86     v0 = np.array([[0.0], [0.0]])
87     vf = np.array([[0.0], [0.0]])
88
89     #
90     # Pre-allocate the storage

```

Nov 30, 23 16:20

## goals9step7c.py

Page 2/5

```

92     N = int(100 * T)           # 100 samples/second.
93     Time = np.array([0.0] * N)
94     PAct = np.array([[0.0] * N] * 2)
95     PCmd = np.array([[0.0] * N] * 2)
96     VAct = np.array([[0.0] * N] * 2)
97     VCmd = np.array([[0.0] * N] * 2)
98     objectpan = np.array([0.5] * N)
99     objecttilt = np.array([0.5] * N)
100    obj = []
101    monitor = []
102    (pan, otilt) = (0.5, 0.5)
103
104    # Initialize the index and time.
105    index = 0
106    t      = 0.0
107
108    #
109    # Maximum Velocities/Accelerations
110    #
111    t_min = np.array([[2], [5]])
112    v_max = 2/3*pi*pi/t_min
113    a_max = v_max/0.25
114
115    #
116    # starred index
117    #
118    starred = 0
119    #
120    # calculate spline parameters
121    #
122    def splineparameters(Tmove, p0, v0, pf, vf):
123        a = p0
124        b = v0
125        c = 3*(pf-p0)/(Tmove**2)-vf/Tmove-2*v0/Tmove
126        d = -2*(pf-p0)/(Tmove**3)+vf/(Tmove**2)+v0/(Tmove**2)
127        return (a, b, c, d)
128
129    def splinetime(p0, pf, v0, vf):
130        return max(npamax(1.5*(np.absolute(p0-pf)/v_max+np.absolute(v0)/a_max+np.absolute(vf)/a_max)), 1)
131    #
132    # Plot.
133    #
134    # Create a plot of position and velocity, actual and command!
135    def plotPos():
136        pan = [m.pan for m in monitor]
137        tilt = [m.tilt for m in monitor]
138        plt.scatter(pan, tilt, marker = "X")
139        plt.xlim(-1.5,1.5)
140        plt.ylim(-1.0, 1.0)
141        plt.title('Goals 9 Step 6 – Monitor Multiple Detection')
142        plt.ylabel('Tilt')
143        plt.xlabel('Pan')
144        for m in monitor:
145            print("tilt", m.tilt, "pan", m.pan, "confidence", m.conf)
146        plt.show()
147
148    def plot():
149        fig, (ax1, ax2) = plt.subplots(2, 1, sharex=True)
150        ax1.plot(Time[0:index], PAct[0][0:index], color='blue', linestyle='-', label='Pan PAct')
151        ax1.plot(Time[0:index], PCmd[0][0:index], color='blue', linestyle='--', label='Pan PCmd')
152        ax1.plot(Time[0:index], objectpan[0:index], color='red', linestyle='.', label='Pan object')
153        ax1.plot(Time[0:index], PAct[1][0:index], color='green', linestyle='-', label='Tilt PAct')
154        ax1.plot(Time[0:index], PCmd[1][0:index], color='green', linestyle='--', label='Tilt PCmd')
155        ax1.plot(Time[0:index], objecttilt[0:index], color='black', linestyle='-.', label='Tilt object')
156
157        ax2.plot(Time[0:index], VAct[0][0:index], color='blue', linestyle='-', label='Pan VAct')
158        ax2.plot(Time[0:index], VCmd[0][0:index], color='blue', linestyle='--', label='Pan VCmd')
159        ax2.plot(Time[0:index], VAct[1][0:index], color='green', linestyle='-', label='Tilt VAct')
160        ax2.plot(Time[0:index], VCmd[1][0:index], color='green', linestyle='--', label='Tilt VCmd')
161
162        ax1.set_title('Goals 9 Step 3 – Cammera Scale and Latency')
163        ax1.set_ylabel('Position (rad)')
164        ax2.set_ylabel('Velocity (rad/s)')
165        ax2.set_xlabel('Time (s)')
166
167        ax1.grid()
168        ax2.grid()
169        ax1.legend(loc = 'lower right')
170        ax2.legend(loc = 'lower right')
171        #plt.scatter(objectpan, objecttilt)
172        plt.show()
173    ##
174    ## Execute Movement
175    ##
176    while True:
177        # Read the actual data. This blocks (internally waits) 10ms for the data.
178        feedback = group.get_next_feedback(reuse_fbk=feedback)
179        pact = np.array([[feedback.position[0]], [feedback.position[1]]])
180        vact = np.array([[feedback.velocity[0]], [feedback.velocity[1]]])
181        # Compute the commands for this time step

```

Nov 30, 23 16:20

## goals9step7c.py

Page 3/5

```

183     A = np.array([[1.0], [0.5]])
184     Tperiod = np.array([[4], [8]])
185     pcmd = A*np.sin(2*pi*(t-t0)/Tperiod)
186     vcmd = A*(2*pi/Tperiod)*np.cos(2*pi*(t-t0)/Tperiod)
187     if t >= tf and len(monitor) > 0:
188         plotPos()
189         starred = 0
190         mode = Mode.Spline
191         p0 = pcmd
192         v0 = vcmd
193         pf = np.array([[monitor[0].pan], [monitor[0].pan]])
194         phold = pf
195         vf = np.array([[0.0], [0.0]])
196         Tmove = splinetime(p0, pf, v0, vf)
197         (a, b, c, d) = splineparameters(Tmove, p0, v0, pf, vf)
198         t0 = t
199         tf = t0 + Tmove
200     elif mode is Mode.Setscan:
201         pcmd = (a + b*(t-t0) + c*(t-t0)**2+d*(t-t0)**3)
202         vcmd = (b + 2*c*(t-t0) + 3*d*(t-t0)**2)
203         if t>=tf:
204             phold= pcmd
205             mode = Mode.Scanning
206             t0 = t
207             tf = t0 + 8
208     elif mode is Mode.Hold:
209         pcmd = phold
210         vcmd = np.array([[0.0], [0.0]])
211         if t >= tf:
212             if starred >= len(monitor):
213                 mode = Mode.Setscan
214                 p0 = pcmd
215                 v0 = vcmd
216                 pf = np.array([[0],[0]])
217                 phold = pf
218                 vf = np.array([[0.0],[0.0]])
219                 Tmove = splinetime(p0, pf, v0, vf)
220                 (a, b, c, d) = splineparameters(Tmove, p0, v0, pf, vf)
221                 t0 = t
222                 tf = t0 + Tmove
223             else:
224                 mode = Mode.Spline
225                 p0 = pcmd
226                 v0 = vcmd
227                 pf = np.array([[monitor[starred].pan], [monitor[starred].pan]])
228                 phold = pf
229                 vf = np.array([[0.0], [0.0]])
230                 Tmove = splinetime(p0, pf, v0, vf)
231                 (a, b, c, d) = splineparameters(Tmove, p0, v0, pf, vf)
232                 t0 = t
233                 tf = t0 + Tmove
234     elif mode is Mode.Setscan:
235         p0 = pcmd
236         v0 = vcmd
237         pf = np.array([[0.0],[0.0]]) + calib
238         print("test: ", pf)
239         vf = np.array([[1.0],[0.25]])
240         Tmove = splinetime(p0, pf, v0, vf)
241         (a, b, c, d) = splineparameters(Tmove, p0, v0, pf, vf)
242         t0 = t
243         tf = t0 + Tmove
244         mode = Mode.Reset
245     elif mode is Mode.Reset:
246         pcmd = (a + b*(t-t0) + c*(t-t0)**2+d*(t-t0)**3)
247         #print("pcmd", pcmd)
248         vcmd = (b + 2*c*(t-t0) + 3*d*(t-t0)**2)
249         #print("reset", pf, pcmd)
250         if t>=tf:
251             mode = Mode.Hold
252             t0 = t
253     elif mode is Mode.Spline:
254         pcmd = (a + b*(t-t0) + c*(t-t0)**2+d*(t-t0)**3)
255         vcmd = (b + 2*c*(t-t0) + 3*d*(t-t0)**2)
256         if t>=tf:
257             starred = starred + 1
258             phold= pcmd
259             mode = Mode.Hold
260             t0 = t
261             tf = t0 + 2
262     else:
263         print("this should never happen")
264     # Send the commands. This returns immediately.
265     command.position = pcmd
266     command.velocity = vcmd
267     group.send_command(command)
268
269     # Store the data for this time step (at the current index).
270     if(index< N):
271         Time[index] = t
272         PAct[0][index], PAct[1][index] = pact[0], pact[1]

```

Nov 30, 23 16:20

## goals9step7c.py

Page 4/5

```

274     VAct[0][index], VAct[1][index] = vact[0], vact[1]
275     VCmd[0][index], VCmd[1][index] = vcmd[0], vcmd[1]
276     objectpan[index] = opan
277     objecttilt[index] = otilt
278 elif index == N:
279     print("plot")
280     # plot()
281 # check if keyboard hit
282 if kbhit():
283     # Take action, based on the character.
284     ch = getch()
285     mode = Mode.Spline
286     if (ch == 'a'):
287         # make robot move without wait
288     p0 = pcmd
289     v0 = vcmd
290     pf = np.array([[-0.15337068238377316], [-0.037060368086649906]]) + calib
291     vf = np.array([[0.0], [0.0]])
292     Tmove = splinetime(p0, pf, v0, vf)
293     (a, b, c, d) = splineparameters(Tmove, p0, v0, pf, vf)
294     print('A: pan: 60, tilt: 0')
295 elif (ch == 'b'):
296     p0 = pcmd
297     v0 = vcmd
298     pf = np.array([[-pi/8], [pi/6]]) + calib
299     vf = np.array([[0.0], [0.0]])
300     Tmove = splinetime(p0, pf, v0, vf)
301     (a, b, c, d) = splineparameters(Tmove, p0, v0, pf, vf)
302     print('B: pan: -45, tilt: -30')
303 elif (ch == 'c'):
304     p0 = pcmd
305     v0 = vcmd
306     pf = np.array([[0],[pi/8]]) + calib
307     vf = np.array([[0.0], [0.0]])
308     Tmove = splinetime(p0, pf, v0, vf)
309     (a, b, c, d) = splineparameters(Tmove, p0, v0, pf, vf)
310     print('C: pan: 60, tilt: 45')
311 elif (ch == 'd'):
312     p0 = pcmd
313     v0 = vcmd
314     pf = np.array([[0],[pi/6]]) + calib
315     vf = np.array([[0.0], [0.0]])
316     Tmove = splinetime(p0, pf, v0, vf)
317     (a, b, c, d) = splineparameters(Tmove, p0, v0, pf, vf)
318     print('D: pan: 0, tilt: -30')
319 elif (ch == 's'):
320     p0 = pcmd
321     v0 = vcmd
322     pf = np.array([[0],[0]])
323     vf = np.array([[0.0], [0.0]])
324     Tmove = splinetime(p0, pf, v0, vf)
325     (a, b, c, d) = splineparameters(Tmove, p0, v0, pf, vf)
326     mode = Mode.Setscan
327     obj = []
328 elif (ch == 'q'):
329     # If we want to quit, break out of the loop.
330     print('Quitting')
331     break
332 else:
333     # Report the bad press.
334     print("Unknown character '%c'" % ch)
335     t0 = np.array(t)
336     tf = np.array(t0 + Tmove)
337 if shared.lock.acquire(timeout=0.001):
338     if shared.newdata and mode is Mode.Scanning:
339         # Compute the object angles.
340         #print("p", shared.deltapan, "t", shared.deltatilt)
341         # Lpan = 0.41709845
342         Lpan = 0.2
343         Ltilt = 0.8
344         R = 0.5
345         minpan = pact[0][0] - vact[0][0] * Lpan - shared.scalepan * 320
346         maxpan = pact[0][0] - vact[0][0] * Lpan + shared.scalepan * 320
347         mintilt = pact[1][0] + vact[1][0] * Ltilt - shared.scaletilt * 240
348         maxtilt = pact[1][0] + vact[1][0] * Ltilt + shared.scaletilt * 240
349         #Ltilt = 0.8100304
350         #Lpan = 0.
351         #Ltilt = 0.1
352         #opan = pact[0][0] - shared.deltapan
353         print("shared", shared.balls)
354         print("monitored", monitor)
355         obj = []
356         for ball in shared.balls:
357             #print(ball.deltapan, ball.deltatilt)
358             opan = pact[0][0] - vact[0][0] * Lpan - ball.deltapan ##+ vact[0][0] * Lpan
359             otilt = pact[1][0] + vact[1][0] * Ltilt + ball.deltatilt
360
361             obj.append(Object(opan, otilt))
362 def closest(mp, mt):
363     minR = 100

```

Nov 30, 23 16:20

## goals9step7c.py

Page 5/5

```

365         flag = False
366         for o in reversed(obj):
367             if(sqrt((o.pan-mp)**2+(o.tilt-mt)**2)<minR):
368                 flag = True
369                 minR = sqrt((o.pan-mp)**2+(o.tilt-mt)**2)
370                 minO = o
371             if flag:
372                 obj.remove(minO)
373             return minO, minR, flag
374         for m in reversed(monitor):
375             cObj, cDist, exist = closest(m.pan, m.tilt)
376             if exist:
377                 if cDist < R:
378                     m = cObj
379                     m.conf = min(m.conf+0.2, 1)
380                 elif m.pan < minpan or m.pan > maxpan or m.tilt < mintilt or m.tilt > maxtilt:
381                     m.conf = m.conf-0.005
382                 if m.conf < -0.5:
383                     monitor.remove(m)
384                 else:
385                     m.conf = m.conf-0.1
386             print(len(obj))
387             for o in reversed(obj):
388                 monitor.append(o)
389             """Lpan = 2.5//1.2
390             Ltilt = 1.71//1.47
391             opan = pact[0][0] - shared.deltapan
392             otilt = pact[1][0] + shared.deltatilt
393             opan = pact[0][0] + vact[0][0] * Lpan - shared.deltapan
394             otilt = pact[1][0] + vact[1][0] * Ltilt + shared.deltatilt"""
395             """mode = Mode.Spline
396             p0 = pact
397             pf = np.array([[opan], [otilt]])
398             v0 = vact
399             vf = np.array([[0], [0]])
400             Tmove = splinetime(p0, pf, v0, vf)
401             (a, b, c, d) = splineparameters(Tmove, p0, v0, pf, vf)
402             t0 = t
403             if t0 + Tmove
404                 print("a=", a, "b=", b, "c =", c, "d=", d)
405                 print('going to object')
406             if(index<N):
407                 objectpan[index] = opan
408                 objecttilt[index] = otilt
409                 # Clear the data.
410                 shared.newdata = False
411                 shared.lock.release()
412             # Check whether we have a new object location.
413             # Advance the index/time.
414             index += 1
415             t      += 0.01

```

Nov 29, 23 22:20

## goals9step7d.py

Page 1/3

```

1  """goals8step8d.py
2
3     Run the face (and eye) detectors and show the results.
4
5
6     # Import OpenCV
7     import numpy as np
8     import cv2
9
10    def detector(shared):
11        class Ball:
12            def __init__(self, pan = 0.5, tilt = 0.5):
13                self.deltapan = pan
14                self.deltatilt = tilt
15                self.conf = 0.2
16
17            # Set up video capture device (camera). Note 0 is the camera number.
18            # If things don't work, you may need to use 1 or 2?
19            #camera = cv2.VideoCapture(0, cv2.CAP_V4L2)
20            camera = cv2.VideoCapture(0, cv2.CAP_ANY)
21
22            if not camera.isOpened():
23                raise Exception("Could not open video device: Maybe change the cam number?")
24
25            # Change the frame size and rate. Note only combinations of
26            # widthxheight and rate are allowed. In particular, 1920x1080 only
27            # reads at 5 FPS. To get 30FPS we downsize to 640x480.
28            camera.set(cv2.CAP_PROP_FRAME_WIDTH, 640)
29            camera.set(cv2.CAP_PROP_FRAME_HEIGHT, 480)
30            camera.set(cv2.CAP_PROP_FPS, 30)
31
32            # Get the face/eye detector models from XML files. Instantiate detectors.
33            faceXML = "haarcascade_frontalface_default.xml"
34            eyeXML1 = "haarcascade_eye.xml"
35            eyeXML2 = "haarcascade_eye_tree_eyeglasses.xml"
36
37            faceDetector = cv2.CascadeClassifier(faceXML)
38            eyeDetector = cv2.CascadeClassifier(eyeXML1)
39
40            # Pick some colors. Note OpenCV uses BGR color codes by default.
41            blue = (255, 0, 0)
42            green = (0, 255, 0)
43            red = (0, 0, 255)
44            white = (255, 255, 255)
45
46            hsv = np.array([])
47            bgr = np.array([])
48
49            #
50            # scale
51            #
52            scalepan = 0.00161932589506
53            scaletilt = 0.00133859370275
54            # Keep scanning, until 'q' hit IN IMAGE WINDOW.
55            while True:
56                # Grab an image from the camera. Often called a frame (part of sequence).
57                ret, frame = camera.read()
58
59                #convert image to hsv
60                hsv = cv2.cvtColor(frame, cv2.COLOR_RGB2HSV)
61
62                # Convert the image to gray scale.
63                gray = cv2.cvtColor(frame, cv2.COLOR_BGR2GRAY)
64
65                # Grab the faces - the cascade detector returns a list faces.
66                faces = faceDetector.detectMultiScale(gray,
67                    scaleFactor = 1.2,
68                    minNeighbors = 5,
69                    minSize = (30,30),
70                    flags = cv2.CASCADE_SCALE_IMAGE)
71
72                # Process the faces: Each face is a bounding box of (x,y,w,h)
73                # coordinates. Draw the bounding box ON THE ORIGINAL IMAGE.
74                if len(faces) > 0:
75                    # Grab the first face.
76                    face = faces[0]
77
78                    # Grab the face coodinates.
79                    (x, y, w, h) = face
80
81                    # Draw the bounding box on the original color frame.
82                    #cv2.rectangle(frame, (x, y), (x+w-1, y+h-1), green, 3)

```

Nov 29, 23 22:20

## goals9step7d.py

Page 2/3

```

84      # Also look for eyes - only within the region of the face!
85      # This similarly a list of eyes relative to this region.
86      eyes = eyeDetector.detectMultiScale(gray[y:y+h,x:x+w])
87
88      # Process the eyes: As before, eyes is a list of bounding
89      # boxes (x,y,w,h) relative to the processed region.
90      for (xe,ye,we,he) in eyes:
91          # Can you draw circles around the eyes? Consider the function:
92          # cv2.circle(frame, (xc, yc), radius, (b,g,r), linewidth)
93          pass # replace this.
94
95
96      # Show the image with the given title. Note this won't actually
97      # appear (draw on screen) until the waitKey(1) below.
98      (H, W, D) = frame.shape
99      #np.append(bgr, frame[W//2, H//2])
100     #np.append(hsv, hsv[W//2, H//2])
101     #print("Frame: ", frame[W//2, H//2])
102     #print("HSV: ", hsv[W//2, H//2])
103
104     #Convert to binary
105     binary = cv2.inRange(hsv, (113, 126, 78), (151, 255, 225))
106     #binary = cv2.inRange(hsv, (107, 142, 119), (119, 255, 255))
107
108     #Erode, then Dilate
109     binary=cv2.erode( binary, None, iterations=3)
110     binary=cv2.dilate(binary, None, iterations=3)
111
112     #Dilate, then Erode
113     binary=cv2.dilate(binary, None, iterations=3)
114     binary=cv2.erode(binary, None, iterations=3)
115
116     #Contours
117     (contours, hierarchy) = cv2.findContours(binary, cv2.RETR_LIST, cv2.CHAIN_APPROX_SIMPLE)
118     contoursTemp = sorted(contours, key=cv2.contourArea, reverse=True)
119     contours=[]
120     (xmax,ymax,rmax) = (0, 0, 0)
121     balls = []
122     for contour in contoursTemp:
123         if cv2.contourArea(contour) > 2000:
124             contours.append(contour)
125             ((xr, yr), radius) = cv2.minEnclosingCircle(contour)
126             cv2.circle(frame, (int(xr), int(yr)), 4, (91, 252, 104), -1)
127             cv2.circle(frame, (int(xr), int(yr)), int(radius), (91, 252, 104), 3)
128             x = scalepan * float(xr - 320)
129             y = scaletilt * float(yr - 240)
130             balls.append(Ball(x, y))
131             #print(xr, yr)
132         if shared.lock.acquire():
133             """if rmax > 0:
134                 (x0, y0, x, y) = (320, 240, xmax, ymax)
135                 shared.deltapan = scalepan * float(x - x0)
136                 shared.deltatilt = scaletilt * float(y - y0)
137                 shared.newdata = True"""
138             shared.balls = balls
139             shared.lock.release()
140             shared.scalepan = scalepan
141             shared.scaletilt = scaletilt
142             shared.newdata = True
143
144     """ENCLOSING CIRCLE"""
145
146
147     cv2.line(frame, (W//2,0), (W//2,H), (0,0,255), 1)
148     cv2.line(frame, (0,H//2), (W, H//2), (0,0,255), 1)
149     cv2.line(hsv, (W//2,0), (W//2,H), (0,0,255), 1)
150     cv2.line(hsv, (0,H//2), (W, H//2), (0,0,255), 1)
151     cv2.imshow('Processed Image', frame)
152     #cv2.imshow('HSV Funkiness', hsv)
153     cv2. imshow('Binary Image', binary)
154
155     # Check for a key press IN THE IMAGE WINDOW: waitKey(0) blocks
156     # indefinitely, waitkey(1) blocks for at most 1ms. If 'q' break.
157     # This also flushes the windows and causes it to actually appear.
158     if (cv2.waitKey(1) & 0xFF) == ord('q'):
159         break
160
161     # Check if the main thread signals this loop to end.
162     if shared.lock.acquire():
163         stop = shared.stop
164         shared.lock.release()
165         if stop:
166             break

```

Nov 29, 23 22:20

## goals9step7d.py

Page 3/3

```
167     camera.release()
168     cv2.destroyAllWindows()
169
170 if __name__ == "__main__":
171     controller()
```